

TUB INSERT FOR FLUID 100 AND 200 *CODE:2D5314*



This insert allows the oil to be removed from the calibrator or replaced with other oil without having to turn the calibrator upside down to drain it, the oil is contained in special removable inserts so that it can be replaced with a dry insert or with another insert containing a different oil. The operation is easily done by removing the insert and the oil in it without siphoning the oil directly from the calibrator but simply removing the insert so that another one can be placed. The operation of removing the low-temperature oil to replace it with another high-temperature oil is thus facilitated. Providing two or more of this inserts facilitates calibration operations by avoiding wastage, pouring or oil spillage.



1. Unscrew the plug.



2. Insert oil up to 3 cm from the top.



3. Screw the cap all the way down and place the insert into the calibrator.



4. Once the insert is inserted, unscrew the cap and proceed with calibrations.



5. In case an oil change needed, remove the insert manually.



6. Drain the oil, clean the insert with paper towels, and fill in with the desired oil.

**CAUTION: TO AVOID BURNS
PERFORM THESE OPERATIONS
WITH THE CALIBRATOR AT
AMBIENT TEMPERATURE**



TESTING
EXPERTISE

GIUSSANI s.r.l.

24045 FARA GERA D'ADDA (Bg) Italy Via Trento, 22
Tel. 0363.399019 – Fax 0363.398725
Internet address: www.giussanionline.it
e-mail: info@giussanionline.it

C.C.I.A.A. BG 211683
C.F. e P. IVA 01496840164
Reg. Trib. Bergamo 23221 Vol.22270
Capitale Sociale L. 20.000.000 i.v.